

## **W8016 Wall Padding - Suggestions for Attaching Padding to a Concrete Wall**

There are many options for attaching this item to a concrete. All will require a drill with a masonry bit. Holes will need to be drilled through the wall panel and then into the concrete.

To secure the wall panel to the concrete the customer could use concrete screws like [Tapcon](#) concrete screws. For more on Tapcon screws visit - <http://www.tapcon.com/products>

A website with some good [instructions](#) with the details on how these types of screws are installed is

<http://www.familyhandyman.com/DIY-Projects/Concrete---Brick/Concrete/drilling-concrete-and-installing-fasteners/View-All>

That same site has a how to guide on selecting the appropriate hardware for installing things into concrete on this page

<http://www.familyhandyman.com/DIY-Projects/Concrete---Brick/Concrete/how-to-choose-and-use-concrete-fasteners/Step-By-Step>