Tecre Co., Inc. Mirror Back Button Instructions

- 1. Place the shell, graphic, then mylar into the pickup die.
- 2. Rotate the die table one-half turn clockwise until the die table is against the outer column.
- 3. Press the handle all the way down, then raise all the way up.
- 4. Place the collet (sharp side up), mirror (reflective side down), then a bent shim into the crimp die.
- 5. Rotate the die table one-half turn counter clockwise.
- 6. Press the handle all the way down, then all the way up.
- 7. Rotate the die table clockwise

Note: You must use a shim that you have bent. (As pictured here) The bent shim will prevent movement of the mirror in the finished mirror button.



