

GP106 - ASSEMBLY NOTE:

Due to manufacturing inconsistencies beyond our control, it may be necessary to use a soft mallet to assemble the wooden disc and dowel in this project. We recommend you test fit the dowels before attempting to glue in place.



GP106 - ASSEMBLY NOTE:

Due to manufacturing inconsistencies beyond our control, it may be necessary to use a soft mallet to assemble the wooden disc and dowel in this project. We recommend you test fit the dowels before attempting to glue in place.



GP106 - ASSEMBLY NOTE:

Due to manufacturing inconsistencies beyond our control, it may be necessary to use a soft mallet to assemble the wooden disc and dowel in this project. We recommend you test fit the dowels before attempting to glue in place.



GP106 - ASSEMBLY NOTE:

Due to manufacturing inconsistencies beyond our control, it may be necessary to use a soft mallet to assemble the wooden disc and dowel in this project. We recommend you test fit the dowels before attempting to glue in place.

